

Download and Install AirAllow

Download and install the AirAllow app from the Google play or the Apple app store.

Search for **AirAllow** or click the link:




Add a New Customer Site

Sites are a way to group SGS controlled doors, users, and access rights into a cohesive system.

1. Press  then **Login** with your partner account
2. Select **Sites**, then  to add a new site
3. Customize the info and press 

To work on the new site, you must switch sites

4. Select the toggle next to the newly created site
- Now that you are in the newly created site, all user, door, schedule and holidays will apply to that site*
Site level must be set from the AirAllow Portal in the sites menu



Add or Delete Door Access Passcodes

Door access passcodes allow users entry to a door. The passcodes can be managed from any phone using a supplied SGS admin access code

5. Press  then **Passcode Management**
6. When prompted, enter the **SGS Admin Code**


The app displays a list of active passcodes

7. Press  to add a new passcode
8. Then press  to save the passcode
9. Press  to delete an active passcode

The active door name is displayed at the top of the keypad.

For the free version of the app, the phone must be within range of the SGS door to manage the configuration¹.

This code can be retrieved or reset by contacting AirAllow support. <https://airallow.zendesk.com/hc/en-us>



¹ AirAllow Pro version supports remote door management.

Download and Install AirAllow

Download and install the AirAllow app from google play or apple app store.


Search for **AirAllow** or click the link:



Change the Display Title & Unlock Duration

The door title displayed to the user is customizable for a smoother entry experience. The amount of time the door stays unlocked is customizable from 0.1 to 30 seconds.

1. Press  then **Door Management**
The app displays a list of active in-range doors
2. Press  to administer the door
3. When prompted, enter the **SGS Admin Code**
4. Enter the **Door Title**, press  to save
5. Press  to force sync the changes to the SGS



Use the Virtual Keypad to Unlock

Door access passcodes allow users entry to a door. Key in your access code on the virtual keypad to unlock.

1. Enter your passcode on the keypad
The system indicates access is granted

The app indicates invalid passcodes

The phone must be within range of the door as indicated at the top of the keypad screen.

